

Battery Charging

1. There are two ways to charge lithium batteries depending on what model glider they are in.
2. If the glider is a newer G3 with an external charging port:
 - a. Connect the charging cable to the external port at the aft end of the glider
 - b. Turn on the charging block
 1. The amperage reading should increase initially, up to ~12
 2. The glider is done charging once the readout is less than 0.5 amps
3. If the glider is a G2, the forward and aft batteries will need to be removed to charge (ex SL592)
 - a. Take glider apart to access both the forward and aft batteries
 - b. The charging cable has three direct charging cables corresponding to the aft, extended battery, and forward battery (the cable is identical for the forward and extended battery).
 - c. Use the charging cable adaptor to plug in to the aft battery first, and then use either of the remaining charging cables to plug into the forward battery.
 - d. Turn on the charging block
 1. The amperage reading should increase initially, up to ~12
 2. The glider is done charging once the readout is less than 0.5 amps
4. When either replacing G2 batteries or after recharging G3 batteries, reset the coulomb counter to 0
 - a. Put `m_coulomb_amphr_total` 0
 - b. Exit reset
 - c. Get `m_coulomb_amphr_total`
5. You can also check the lithium battery relative charge
 - a. Get `m_lithium_battery_relative_charge`
6. Other relevant battery commands
 - a. `m_battery`
 - b. `m_battery_inst`
 - c. `m_coulomb_amphr_total`
 - d. `m_coulomb_current`
 - e. `m_lithium_battery_relative_charge`